





All Camera and Group information is entered into the master database. The master database is then read by every software application.

For NVR's not containing the master database, a valid SS32 shortcut, and the database path specifying the master database, is all that's needed.

Each Camera's client archive path, must reflect its NVR's ip address/dns name



Legend

Camera Path 

Database Path 

